

UTC

**CONTENTS**

- Description ..... 3
- Installation ..... 6
- Layout and comands ..... 13
- Electric diagram and connections ..... 15
- Changing frequency ..... 10
- Block diagrams and descriptions..... 14
- Technical specifications ..... 15
- Guarantee ..... 16



**WARNING !**

The use and installation of the radio control must be carried out exclusively by qualified and authorized personnel. Incorrect use or installation can cause serious injury to people and damage to objects. This instruction manual must be **READ CAREFULLY** before any attempt is made to install and/or operate the REMdevice radio control.

## DESCRIPTION

The radio control consists of a UTC transmitter unit (Model UTC) and a Receiver RxDIN unit (URC Receiver), both units are fitted with an external antenna.

The two units are housed in standard DIN modules for installing inside the electric panel.

The transmitter contains:

- 22 ON/OFF simultaneous inputs,
- 1 GEAR input (for turning on the radio control)
- 2 STOP link-up inputs (to enable the radio control and to use the safety devices)

The inputs can be controlled by signals coming from the PLC, switches or relays.

For each of the Transmitter inputs the Receiver has a relay contact output.

For the GEAR input there are two relay contact outputs for GEAR and CLAXON. While for the STOP\_A and STOP\_B there are two relay contact outputs, one for the safety STOP and one for LAMP.

There are various models available depending on the Frequency Band required (434Mhz or 870Mhz) and the type of power supply available. For more information please refer to the chapter on TECHNICAL SPECIFICATIONS.

Within the 870 frequency range it is possible to program the operation of the system either to continuous transmission (duty cycle 100%) or to impulse transmission to each 340 ms (duty cycle <10%). With the latter option, it is also possible to choose from two different PASSIVE EMERGENCY time values, that is the maximum arrival time of the correct digital data before the safe disactivation of the outputs.

### Serial Numbers

Each radio control is identified by a unique serial number printed on the transparent cover of the Transmitter and Receiver units.

## UTC Transmitter Unit




Figure 1

### External ANTENNA




Figure 2

## RxDIN Receiver unit




Figure 3

### External ANTENNA




Figure 4

## INSTALLATION

The installation of the radio control is to be undertaken solely by qualified and competent personnel that have agreed to assume total responsibility for possible damage to people or objects caused by the incorrect wiring, non observation of safety regulations, the use of unsuitable materials and tools or for the incorrect or lack of proper testing of the apparatus.

**Installation engineers are invited to contact REMdevice for help with technical information in order to ensure the correct installation and the starting up of the apparatus.**

### Power supply

Using a voltmeter check the power supply to the electric panel is suitable for the Transmitter and Receiver modules. Refer to the chapter TECHNICAL SPECIFICATIONS for the correct power supply required, this is also reported on the label on the terminals. The wires, phase and neutral or positive and negative, can be put in any position.

When power is supplied to the Transmitter the green ON led comes on and the green led TX\_ON flashes.

When power is supplied to the Receiver the green ON led comes on and the green led PLL flashes regularly.

### Switching on

Connect the STOP\_A and STOP\_B inputs (which must always be present) and GEAR input of the Transmitter. Press GEAR once and check the green led TX\_ON flashes regularly, this confirms the unit is switched on (see Figure 5). On the Receiver, the three green leds (ON, LINK and PLL) come on and the STOP and LAMP contacts close. As long as the GEAR is activated, the START and CLAXON contacts remain closed.

### Functions Change

By inserting an electric bridge on the POWER connector (figure 1) the output power of the Transmitter is reduced.

## ELECTRIC DIAGRAMS AND CONNECTIONS

### UTC connections ELECTRIC DIAGRAM




Figure 5

The outputs are connected to the **OUT+** voltage checker either via the switches or directly to a circuit board or PLC with outputs from **5 to 24Vdc**.

### Transmitter Fuses

- Power supply fuses 5x20 0,5 A

The fuses are located inside the DIN module under the transparent plastic top (see figure 1).

## RxDIN Connection ELECTRIC DIAGRAM




Figure 6





Figure 7

### Receiver Fuses

- STOP Fuse 5x20 4 A
- Power supply fuse 10-30 Vdc 5x20 1,6 A
- Power supply fuse 24-48 Vac/Vdc 5x20 1 A
- Power supply fuse 48-115 Vac/Vdc 5x20 0,5 A

The fuses are located inside the DIN module under the transparent plastic top (see figure 3).

### External Antenna for UTC Transmitter & URC Receiver Rx/DIN

The antennas for the UTC Transmitter and URC Receiver are the same. They should be placed on the outside of the electric panel, each with the long side facing the other. Drill a 16 mm diameter hole on the side of the panel to fix them in place. Use the tightening nut of the wire exit hole to hold the antenna in place.

Pay particular attention to the correct connection of the antenna wires to the Transmitter and Receiver. The holding nuts are relatively small and once it is ensured the connector is properly inserted the nut must be correctly tightened.




Figure 8

### CHANGING FREQUENCY

Change the frequency on both the **Transmitter** and **Receiver** in the same way.

Open the transparent cover (Figures 1 and 3) and using a pointed tip, move one or more of the microswitches (FREQUENCY CHANGE) into a new position. Refer to the following channel frequency tables and paying close attention to the Frequency Band of the radio control. Once finished properly close the transparent cover.




Figure 9

**Frequency 433 I°**

freq MHz	Channel	DIP-switch						on off
		1	2	3	4	5	6	
433,0750	1	o	o	o	o	o	o	on off
433,1000	2	o	o	o	o	o	o	on off
433,1250	3	o	o	o	o	o	o	on off
433,1500	4	o	o	o	o	o	o	on off
433,1750	5	o	o	o	o	o	o	on off
433,2000	6	o	o	o	o	o	o	on off
433,2250	7	o	o	o	o	o	o	on off
433,2500	8	o	o	o	o	o	o	on off
433,2750	9	o	o	o	o	o	o	on off
433,3000	10	o	o	o	o	o	o	on off
433,3250	11	o	o	o	o	o	o	on off
433,3500	12	o	o	o	o	o	o	on off
433,3750	13	o	o	o	o	o	o	on off
433,4000	14	o	o	o	o	o	o	on off
433,4250	15	o	o	o	o	o	o	on off
433,4500	16	o	o	o	o	o	o	on off
433,4750	17	o	o	o	o	o	o	on off
433,5000	18	o	o	o	o	o	o	on off
433,5250	19	o	o	o	o	o	o	on off
433,5500	20	o	o	o	o	o	o	on off
433,5750	21	o	o	o	o	o	o	on off
433,6000	22	o	o	o	o	o	o	on off
433,6250	23	o	o	o	o	o	o	on off
433,6500	24	o	o	o	o	o	o	on off
433,6750	25	o	o	o	o	o	o	on off
433,7000	26	o	o	o	o	o	o	on off
433,7250	27	o	o	o	o	o	o	on off
433,7500	28	o	o	o	o	o	o	on off
433,7750	29	o	o	o	o	o	o	on off
433,8000	30	o	o	o	o	o	o	on off

**Frequency 433 II°**

freq MHz	Channel	DIP-switch						on off
		1	2	3	4	5	6	
434,0750	31	o	o	o	o	o	o	on off
434,1000	32	o	o	o	o	o	o	on off
434,1250	33	o	o	o	o	o	o	on off
434,1500	34	o	o	o	o	o	o	on off
434,1750	35	o	o	o	o	o	o	on off
434,2000	36	o	o	o	o	o	o	on off
434,2250	37	o	o	o	o	o	o	on off
434,2500	38	o	o	o	o	o	o	on off
434,2750	39	o	o	o	o	o	o	on off
434,3000	40	o	o	o	o	o	o	on off
434,3250	41	o	o	o	o	o	o	on off
434,3500	42	o	o	o	o	o	o	on off
434,3750	43	o	o	o	o	o	o	on off
434,4000	44	o	o	o	o	o	o	on off
434,4250	45	o	o	o	o	o	o	on off
434,4500	46	o	o	o	o	o	o	on off
434,4750	47	o	o	o	o	o	o	on off
434,5000	48	o	o	o	o	o	o	on off
434,5250	49	o	o	o	o	o	o	on off
434,5500	50	o	o	o	o	o	o	on off
434,5750	51	o	o	o	o	o	o	on off
434,6000	52	o	o	o	o	o	o	on off
434,6250	53	o	o	o	o	o	o	on off
434,6500	54	o	o	o	o	o	o	on off
434,6750	55	o	o	o	o	o	o	on off
434,7000	56	o	o	o	o	o	o	on off
434,7250	57	o	o	o	o	o	o	on off
434,7500	58	o	o	o	o	o	o	on off
434,7750	59	o	o	o	o	o	o	on off

### Frequency 870

freq MHz	Channel		DIP-switch						on/off
			1	2	3	4	5	6	
869,7000	1	CONTINUOUS TRANSMISSION DUTY CYCLE 100%	o	o	o	o	o	o	on
869,7250	2		o	o	o	o	o	o	on
869,7500	3		o	o	o	o	o	o	on
869,7750	4		o	o	o	o	o	o	on
869,8000	5		o	o	o	o	o	o	on
869,8250	6		o	o	o	o	o	o	on
869,8500	7		o	o	o	o	o	o	on
869,8750	8		o	o	o	o	o	o	on
869,9000	9		o	o	o	o	o	o	on
869,9250	10		o	o	o	o	o	o	on
869,9500	11		o	o	o	o	o	o	on
869,4125	1	IMPULSE TRANSMISSION DUTY CYCLE <10% EMERGENCY 1 s	o	o	o	o	o	o	on
869,4375	2		o	o	o	o	o	o	on
869,4625	3		o	o	o	o	o	o	on
869,4875	4		o	o	o	o	o	o	on
869,5125	5		o	o	o	o	o	o	on
869,5375	6		o	o	o	o	o	o	on
869,5625	7		o	o	o	o	o	o	on
869,5875	8		o	o	o	o	o	o	on
869,6125	9		o	o	o	o	o	o	on
869,6375	10		o	o	o	o	o	o	on
869,4125	1	IMPULSE TRANSMISSION DUTY CYCLE <10% EMERGENCY 1.8 s	o	o	o	o	o	o	on
869,4375	2		o	o	o	o	o	o	on
869,4625	3		o	o	o	o	o	o	on
869,4875	4		o	o	o	o	o	o	on
869,5125	5		o	o	o	o	o	o	on
869,5375	6		o	o	o	o	o	o	on
869,5625	7		o	o	o	o	o	o	on
869,5875	8		o	o	o	o	o	o	on
869,6125	9		o	o	o	o	o	o	on
869,6375	10		o	o	o	o	o	o	on




Figure 10

### Description of Transmitter Unit

The commands sent via the transmitter unit are processed by the microprocessor that supplies a linking telegram containing a unique identification code. They are then sent to the TX module by radio frequency.

### Description of Receiver Unit

The RX module receives the linking telegram and is processed by the µP A microprocessor that verifies the authenticity of the telegram by checking its unique identification code. If the commands received are confirmed to be valid the microprocessor activates the corresponding relays.

If an active or passive emergency command is activated or in the case of disturbance or lack of signal, the µP A microprocessor stops the machine being operated (safety system 1).

In turn, microprocessor µP B checks the correct functioning of microprocessor µP A and intervenes in the case of a direct breakdown to the control and safety relays (safety system 2).

## TECHNICAL SPECIFICATIONS

### Transmitter unit

Modulation: FM Manchester  
Radio frequency output power: 5 mW  
Oscillator: digital synthesizing PLL  
Antenna:  $\frac{1}{4} \lambda$   
Power supply (depending on model):  
DC 10-30V - 1,0A or AC/DC 24-48 or AC/DC 48-115 - 50-60 Hz - 0,4A  
Container: Modulbox for fixing on bracket DIN EN 50022  
Protection Modulbox: IP20  
Dimensions Modulbox: 158×90×75 mm (L×H×D)

### Receiver unit

Radio frequency receiver unit: Single Chip  
Antenna:  $\frac{1}{4} \lambda$   
Commands relay contacts capacity: 4A 115 Vac.  
Stop relay contacts capacity: 4A 115 Vac.  
Power supply (depending on model):  
DC 10-30V - 1,0A or AC/DC 24-48 or AC/DC 48-115 - 50-60 Hz - 0,4A  
Container: Modulbox for fixing on bracket DIN EN 50022  
Protection Modulbox: IP20  
Dimensions Modulbox: 158×90×75 mm (L×H×D)

### Parameters common to both units

Frequency range:  
869,700– 870,000 MHz/ Frequency steps 25kHz/ 11 channels  
869,400– 869,650 MHz/ Frequency steps 25kHz/ 10 channels\*  
433,050– 434,790 MHz/ Frequency steps 25kHz/ 59 channels  
Hamming distance: 4  
Maximum simultaneous on/off command: 22  
Command response time: 30 ms  
Active emergency stop command response time: 30 ms  
Passive emergency command response time: 1 or 1,8 s  
Transmission range: 100 m  
Working/storage temperature: -20°C / +70°C  
\* Duty cycle mode: <10%  
- Command response time: 340 ms  
- Active emergency stop response time: 340 ms

## CONDITIONS OF GUARANTEE

REMdevice guarantees the radio control unit for 1 year.  
The guarantee commences from the date of the Transport Document.  
The guarantee is only valid for equipment with manufacturing defects. The radio control unit MUST NOT be subjected to attempted repairs, tampering or replacement of parts by persons not authorised by REMdevice.  
The guarantee becomes void in the case of incorrect usage or errors in installation.  
Equipment under guarantee must be repaired only at authorised assistance centres or by REMdevice.  
Parts with manufacturing defects will be replaced free of charge excluding return transport costs of the equipment.  
Wear and tear to parts is not covered by the guarantee.  
REMdevice is not liable to give compensation for machine stoppage in that the machines to be operated are equipped with cabled keypads.  
REMdevice is not liable for any damage, loss or theft of new, repaired or to be repaired equipment during transportation.  
REMdevice will not carry out repairs to equipment (whether under guarantee or not) that has no serial number and without having previous contact with the owner.

Manufacturer: **REMdevice**® s.r.l. E-Mail: info@remdevice.com  
Web: remdevice.com

Head Office & R&D Dept

**REMdevice** s.r.l.  
via Roma n. 27  
28010 Bogogno  
ITALY

Administration, Sales & Production Dept

**REMdevice** s.r.l.  
via Mantegna n. 12  
36061 Bassano del Grappa  
ITALY  
TEL +39 0424 500 262  
FAX +39 0424 508 631

*Copyright © 2006 – REMdevice® s.r.l. All rights reserved.  
The information contained in this manual has been carefully checked, in that we have endeavoured to ensure that it is precise and complete, however, REMdevice declines all responsibility for any possible errors or omissions.  
REMdevice reserves the right to change the specifications describe in this manual at any time without prior notice.  
The reproduction, transmission, transcription or storage in a information research system of this manual is expressly forbidden, either in whole or in part, and its translation into another language in any form, without previous written permission from REMdevice® s.r.l.*